

Package ‘MSRDT’

July 21, 2025

Type Package

Title Multi-State Reliability Demonstration Tests (MSRDT)

Version 0.1.0

Maintainer Suiyao Chen <csytsy12377@gmail.com>

Description This is a implementation of design methods for multi-state reliability demonstration tests (MSRDT) with failure count data, which is associated with the work from the published paper ``Multi-state Reliability Demonstration Tests" by Suiyao Chen et al. (2017) <[doi:10.1080/08982112.2017.1314493](https://doi.org/10.1080/08982112.2017.1314493)>. It implements two types of MSRDT, multiple periods (MP) and multiple failure modes (MFM). For MP, two different scenarios with criteria on cumulative periods (Cum) or separate periods (Sep) are implemented respectively. It also provides the implementation of conventional design method, namely binomial tests for failure count data.

Depends R (>= 3.3.0)

License GPL-3

Encoding UTF-8

LazyData true

RoxygenNote 7.1.0

Imports gtools, stats, reshape2, dplyr, utils

Suggests tidyverse, knitr, rmarkdown

URL <https://github.com/ericchen12377/MSRDT>

BugReports <https://github.com/ericchen12377/MSRDT/issues>

VignetteBuilder knitr

NeedsCompilation no

Author Suiyao Chen [aut, cre]

Repository CRAN

Date/Publication 2020-06-02 10:00:02 UTC

Contents

bconsumerrisk	2
bcore	3
bIndicator	4
boptimal_n	4
MFM_consumerrisk	5
MFM_core	6
MFM_Indicator	7
MFM_optimal_n	8
MPCum_consumerrisk	9
MPCum_core	9
MPCum_optimal_n	10
MPSep_consumerrisk	11
MPSep_core	12
MPSep_optimal_n	12
MP_Indicator	13
pi_MCSim_beta	14
pi_MCSim_dirichlet	14
Index	16

bconsumerrisk	<i>Consumer's Risk for Binomial RDT</i>
---------------	---

Description

Define the consumer's risk function which gets the probability of passing the test when the lower level reliability requirement is not satisfied (for binomial RDT).

Usage

```
bconsumerrisk(n, c, pi, R)
```

Arguments

- | | |
|----|--------------------------------------|
| n | RDT sample size. |
| c | Maximum allowable failures. |
| pi | Failure probability. |
| R | Lower level reliability requirement. |

Value

Probability of consumer's risk

See Also

[bcore](#) for getting the core probability of passing the test; [boptimal_n](#) for getting the optimal test sample size; [bIndicator](#) for getting the binary indicator;

Other Binomial RDT functions: [bIndicator\(\)](#), [bcore\(\)](#), [boptimal_n\(\)](#)

Examples

```
pi <- pi_MCSim_beta(M = 1000, seed = 10, a = 1, b = 1)
bconsumerrisk(n = 10, c = 2, pi = pi, R = 0.8);
```

bcore	<i>Probability Core for Binomial RDT</i>
-------	--

Description

Define the summed core function inside of the integration which gets the probability of passing the test given specific failure probabilities (for binomial RDT).

Usage

```
bcore(n, c, pi)
```

Arguments

n	RDT sample size.
c	Maximum allowable failures.
pi	Failure probability.

Value

Core probability of passing the test given specific failure probabilities.

See Also

[boptimal_n](#) for getting the optimal test sample size; [bconsumerrisk](#) for getting the consumer's risk; [bIndicator](#) for getting the binary indicator;

Other Binomial RDT functions: [bIndicator\(\)](#), [bconsumerrisk\(\)](#), [boptimal_n\(\)](#)

Examples

```
bcore(n = 10, c = 2, pi = 0.2)
```

bIndicator

Binary Indicator for Binomial RDT

Description

Define the binary indicator function to check whether the failure probability satisfies the lower level reliability requirement (for binomial RDT).

Usage

```
bIndicator(pi, R)
```

Arguments

pi	Failure probability.
R	Lower Level reliability requirement.

Value

0 – No; 1 – Yes.

See Also

[bcore](#) for getting the core probability of passting the test; [boptimal_n](#) for getting the optimal test sample size; [bconsumerrisk](#) for getting the consumer's risk;

Other Binomial RDT functions: [bconsumerrisk\(\)](#), [bcore\(\)](#), [boptimal_n\(\)](#)

Examples

```
bIndicator(pi = 0.05, R = 0.9)
bIndicator(pi = 0.2, R = 0.9)
```

boptimal_n

Optimal Test Sample Size for Binomial RDT

Description

Define the optimal function to find the optimal test plan with minimum test sample size given an acceptable level of consumer's risk (for binomial RDT).

Usage

```
boptimal_n(c, pi, R, thres_CR)
```

Arguments

c	Maximum allowable failures
pi	Failure probability
R	Lower level reliability requirement
thres_CR	Threshold (acceptable level) of consumer's risk

Value

Minimum test sample size

See Also

[bcore](#) for getting the core probability of passting the test; [bconsumerrisk](#) for getting the consumer's risk; [bIndicator](#) for getting the binary indicator;

Other Binomial RDT functions: [bIndicator\(\)](#), [bconsumerrisk\(\)](#), [bcore\(\)](#)

Examples

```
pi <- pi_MCSim_beta(M = 5000, seed = 10, a = 1, b = 1)
boptimal_n(c = 2, pi = pi, R = 0.8, thres_CR = 0.05)
```

MFM_consumerrisk	<i>Consumer's Risk for Multi-state RDT with Multiple Failure Modes (MFM)</i>
------------------	--

Description

Define the consumer risk function which gets the probability of passing the test when the lower level reliability requirements are not satisfied under different failure modes (for Multi-state RDT, Multiple Failure Modes).

Usage

```
MFM_consumerrisk(n, cvec, pivec, Rvec)
```

Arguments

n	RDT sample size
cvec	Maximum allowable failures for each separate period
pivec	Failure probability for each sepearte period
Rvec	Lower level reliability requirements for each cumulative period from the beginning of the test.

Value

Probability for consumer’s risk

See Also

[MFM_core](#) for getting the core probability of passting the test; [MFM_Indicator](#) for getting the binary indicator; [MFM_optimal_n](#) for getting the optimal test sample size;
Other MSRDT for MFM functions: [MFM_Indicator\(\)](#), [MFM_core\(\)](#), [MFM_optimal_n\(\)](#)

Examples

```
pi1 <- pi_MCSim_beta(M = 1000, seed = 10, a = 1, b = 1)
pi2 <- pi_MCSim_beta(M = 1000, seed = 10, a = 2, b = 18)
MFM_consumerrisk(n = 10, cvec = c(1, 1), pivec = cbind(pi1, pi2), Rvec = c(0.8, 0.7))
```

MFM_core	<i>Probability Core for Multi-state RDT with Multiple Failure Modes (MFM)</i>
----------	---

Description

Define the summed core function inside of the integration which gets the probability of passing the test given specific failure probabilities under different failure modes (for Multi-state RDT, Multiple Failure Modes).

Usage

```
MFM_core(n, cvec, pivec)
```

Arguments

- n RDT sample size
- cvec Maximum allowable failures for each separate period
- pivec Failure probability for each seperate period

Value

Core probability of passing the test given specific failure probabilities

See Also

[MFM_consumerrisk](#) for getting the consumer’s risk; [MFM_Indicator](#) for getting the binary indicator; [MFM_optimal_n](#) for getting the optimal test sample size;
Other MSRDT for MFM functions: [MFM_Indicator\(\)](#), [MFM_consumerrisk\(\)](#), [MFM_optimal_n\(\)](#)

Examples

```
#' #Example for two failure modes
pi1 <- pi_MCSim_beta(M = 1000, seed = 10, a = 1, b = 1)
pi2 <- pi_MCSim_beta(M = 1000, seed = 10, a = 2, b = 18)
MFM_core(n = 10, cvec = c(1, 1), pivec = c(pi1[1], pi2[1]));
#The function also works for more than two failure modes.
#However, the computation cost may increase.
#Example for three failure modes
MFM_core(n = 10, cvec = c(1, 1, 1), pivec = c(0.8, 0.9, 0.8));
```

MFM_Indicator	<i>Binary Indicator for Multi-state RDT with Multiple Failure Modes (MFM)</i>
---------------	---

Description

Define the binary indicator function to check whether the failure probability satisfies the lower level reliability requirements for each failure mode (for Multi-state RDT, Multiple Failure Models)

Usage

```
MFM_Indicator(pivec, Rvec)
```

Arguments

pivec	Failure probability for each separate period.
Rvec	Lower level reliability requirements for each cumulative period from the beginning of the test.

Value

0 – No; 1 – Yes.

See Also

[MFM_core](#) for getting the core probability of passing the test; [MFM_consumerrisk](#) for getting the consumer's risk; [MFM_optimal_n](#) for getting the optimal test sample size;

Other MSRDT for MFM functions: [MFM_consumerrisk\(\)](#), [MFM_core\(\)](#), [MFM_optimal_n\(\)](#)

Examples

```
MFM_Indicator(pivec = c(0.1, 0.2), Rvec = c(0.8, 0.6))
MFM_Indicator(pivec = c(0.1, 0.2, 0.1), Rvec = c(0.8, 0.6, 0.4))
MFM_Indicator(pivec = c(0.1, 0.4), Rvec = c(0.8, 0.7))
```

MFM_optimal_n	<i>Optimal Test Sample Size for Multi-state RDT with Multiple Failure Modes (MFM)</i>
---------------	---

Description

Define the optimal function to find the optimal test plan with minimum test sample size given an acceptable level of consumer’s risk (for Multi-state RDT, Multiple Failure Modes).

Usage

```
MFM_optimal_n(cvec, pivec, Rvec, thres_CR)
```

Arguments

cvec	Maximum allowable failures for each separate period
pivec	Failure probability for each separate period
Rvec	Lower level reliability requirements for each cumulative period from the beginning of the test.
thres_CR	Threshold (acceptable level) of consumer’s risk

Value

Minimum test sample size

See Also

[MFM_core](#) for getting the core probability of passting the test; [MFM_consumerrisk](#) for getting the consumer’s risk; [MFM_Indicator](#) for getting the binary indicator;

Other MSRDT for MFM functions: [MFM_Indicator\(\)](#), [MFM_consumerrisk\(\)](#), [MFM_core\(\)](#)

Examples

```
pi1 <- pi_MCSim_beta(M = 5000, seed = 10, a = 1, b = 1)
pi2 <- pi_MCSim_beta(M = 5000, seed = 10, a = 2, b = 18)
MFM_optimal_n(cvec = c(1, 1), pivec = cbind(pi1, pi2), Rvec = c(0.8, 0.7), thres_CR = 0.05)
```

MPCum_consumerrisk	<i>Consumer's Risk for Multi-state RDT with Multiple Periods and Criteria for Cumulative Periods</i>
--------------------	--

Description

Define the consumer risk function which gets the probability of passing the test when the lower level reliability requirements are not satisfied for any cumulative periods. The maximum allowable failures for each cumulative period need to be satisfied to pass the test (for Multi-state RDT, Multiple Periods, Scenario I)

Usage

```
MPCum_consumerrisk(n, cvec, pivec, Rvec)
```

Arguments

n	RDT sample size
cvec	Maximum allowable failures for each separate period
pivec	Failure probability for each separate period
Rvec	Lower level reliability requirements for each cumulative period from the beginning of the test.

Value

Probability for consumer's risk

Examples

```
pi <- pi_MCSim_dirichlet(M = 1000, seed = 10, par = c(1, 1, 1))
MPCum_consumerrisk(n = 10, cvec = c(1, 1), pivec = pi, Rvec = c(0.8, 0.7))
```

MPCum_core	<i>Probability Core for Multi-state RDT with Multiple Periods and Criteria for Cumulative Periods</i>
------------	---

Description

Define the summed core function inside of the integration which gets the probability of passing the test given specific failure probabilities. The maximum allowable failures for each cumulative period need to be satisfied to pass the test (for Multi-state RDT, Multiple Periods, Scenario I).

Usage

```
MPCum_core(n, cvec, pivec)
```

Arguments

n	RDT sample size
cvec	Maximum allowable failures for each separate period
pivec	Failure probability for each separate period

Value

Core probability of passing the test given specific failure probabilities

Examples

```
#Example for two periods
pi <- pi_MCSim_dirichlet(M = 1000, seed = 10, par = c(1, 1, 1))
MPCum_core(n = 10, cvec = c(1, 1), pivec = pi[1, ]);
#The function also works for more than two periods, however, may increase the computation cost.
#Example for three periods
pi <- pi_MCSim_dirichlet(M = 1000, seed = 10, par = c(1, 1, 1, 1))
MPCum_core(n = 10, cvec = c(1, 1, 1), pivec = pi[1, ];
```

MPCum_optimal_n	<i>Optimal Test Sample Size for Multi-state RDT with Multiple Periods and Criteria for Cumulative Periods</i>
-----------------	---

Description

Define the optimal function to find the optimal test plan with minimum test sample size given an acceptable level of consumer's risk. The maximum allowable failures for each cumulative period need to be satisfied to pass the test (for Multi-state RDT, Multiple Periods, Scenario I)

Usage

```
MPCum_optimal_n(cvec, pivec, Rvec, thres_CR)
```

Arguments

cvec	Maximum allowable failures for each separate period
pivec	Failure probability for each separate period
Rvec	Lower level reliability requirements for each cumulative period from the beginning of the test.
thres_CR	Threshold (acceptable level) of consumer's risk

Value

Minimum test sample size

Examples

```
pi <- pi_MCSim_dirichlet(M = 5000, seed = 10, par = c(1, 1, 1))
MPCum_optimal_n(cvec = c(1,1), pivec = pi, Rvec = c(0.8, 0.7), thres_CR = 0.05)
```

MPSep_consumerrisk	<i>Consumer's Risk for Multi-state RDT with Multiple Periods and Criteria for Separate Periods</i>
--------------------	--

Description

Define the consumer risk function which gets the probability of passing the test when the lower level reliability requirements are not satisfied for any cumulative periods. The maximum allowable failures for each separate period need to be satisfied to pass the test (for Multi-state RDT, Multiple Periods, Scenario I)

Usage

```
MPSep_consumerrisk(n, cvec, pivec, Rvec)
```

Arguments

n	RDT sample size
cvec	Maximum allowable failures for each separate period
pivec	Failure probability for each separate period
Rvec	Lower level reliability requirements for each cumulative period from the beginning of the test.

Value

Probability for consumer's risk

Examples

```
pi <- pi_MCSim_dirichlet(M = 1000, seed = 10, par = c(1, 1, 1))
MPSep_consumerrisk(n = 10, cvec = c(1, 1), pi = pi, Rvec = c(0.8, 0.7))
```

MPSep_core	<i>Probability Core for Multi-state RDT with Multiple Periods and Criteria for Separate Periods</i>
------------	---

Description

Define the summed core function inside of the integration which gets the probability of passing the test given specific failure probabilities. The maximum allowable failures for each separate period need to be satisfied to pass the test (for Multi-state RDT, Multiple Periods, Scenario II).

Usage

```
MPSep_core(n, cvec, pivec)
```

Arguments

n	RDT sample size
cvec	Maximum allowable failures for each separate period
pivec	Failure probability for each separate period

Value

Core probability of passing the test given specific failure probabilities

Examples

```
#Example for two periods
pi <- pi_MCSim_dirichlet(M = 1000, seed = 10, par = c(1, 1, 1))
MPSep_core(n = 10, cvec = c(1, 1), pivec = pi[1, ]);
#The function also works for more than two periods, however, may increase the computation cost.
#Example for three periods
pi <- pi_MCSim_dirichlet(M = 1000, seed = 10, par = c(1, 1, 1, 1))
MPSep_core(n = 10, cvec = c(1, 1, 1), pivec = pi[1, ];
```

MPSep_optimal_n	<i>Optimal Test Sample Size for Multi-state RDT with Multiple Periods and Criteria for Separate Periods</i>
-----------------	---

Description

Define the optimal function to find the optimal test plan with minimum test sample size given an acceptable level of consumer's risk. The maximum allowable failures for each separate period need to be satisfied to pass the test (for Multi-state RDT, Multiple Periods, Scenario I)

Usage

```
MPSep_optimal_n(cvec, pivec, Rvec, thres_CR)
```

Arguments

cvec	Maximum allowable failures for each separate period
pivec	Failure probability for each separate period
Rvec	Lower level reliability requirements for each cumulative period from the beginning of the test.
thres_CR	Threshold (acceptable level) of consumer's risk

Value

Minimum test sample size

Examples

```
pi <- pi_MCSim_dirichlet(M = 5000, seed = 10, par = c(1, 1, 1))
MPSep_optimal_n(cvec = c(1, 1), pivec = pi, Rvec = c(0.8, 0.7), thres_CR = 0.05)
```

MP_Indicator

Binary Indicator for Multi-state RDT with Multiple Periods

Description

Define the binary indicator function to check whether the failure probability satisfies the lower level reliability requirements for each cumulative period (for Multi-state RDT, Multiple Periods)

Usage

```
MP_Indicator(pivec, Rvec)
```

Arguments

pivec	Failure probability for each separate period.
Rvec	Lower level reliability requirements for each cumulative period from the beginning of the test.

Value

0 – No; 1 – Yes.

Examples

```
MP_Indicator(pivec = c(0.1, 0.2), Rvec = c(0.8, 0.6))
MP_Indicator(pivec = c(0.1, 0.2, 0.1), Rvec = c(0.8, 0.6, 0.4))
MP_Indicator(pivec = c(0.1, 0.3), Rvec = c(0.8, 0.7))
```

pi_MCSim_beta

Beta Prior Simulation for Binomial RDT

Description

Define the simulation function to generate failure probability with Beta prior distributions as conjugate prior to binomial distributions (for binomial RDT).

Usage

```
pi_MCSim_beta(M, seed, a, b)
```

Arguments

M	Simulation sample size
seed	Random seed for random sample
a	Shape parameter 1 for beta distribution
b	Shape parameter 2 for beta distribution

Value

Vector of failure probability sample values

See Also

[pi_MCSim_dirichlet](#)

Other Prior distribution generation functions: [pi_MCSim_dirichlet\(\)](#)

Examples

```
pi <- pi_MCSim_beta(M = 1000, seed = 10, a = 1, b = 1)
```

pi_MCSim_dirichlet

Dirichlet Prior Simulation for Multi-state RDT

Description

Define the simulation function to generate failure probability with Dirichlet prior distributions as conjugate prior to multinomial distributions (for multi-state RDT).

Usage

```
pi_MCSim_dirichlet(M, seed, par)
```

Arguments

M	Simulation sample size
seed	Random seed for random sample
par	Parameters for dirichlet distribution

Value

Vector of failure probability sample

See Also

[pi_MCSim_beta](#)

Other Prior distribution generation functions: [pi_MCSim_beta\(\)](#)

Examples

```
pi <- pi_MCSim_dirichlet(M = 1000, seed = 10, par = c(1, 1, 1))
```

Index

* Binomial RDT functions

bconsumerrisk, [2](#)
bcore, [3](#)
bIndicator, [4](#)
boptimal_n, [4](#)

* MSRDT for MFM functions

MFM_consumerrisk, [5](#)
MFM_core, [6](#)
MFM_Indicator, [7](#)
MFM_optimal_n, [8](#)

* Prior distribution generation functions

pi_MCSim_beta, [14](#)
pi_MCSim_dirichlet, [14](#)

bconsumerrisk, [2](#), [3–5](#)
bcore, [3](#), [3](#), [4](#), [5](#)
bIndicator, [3](#), [4](#), [5](#)
boptimal_n, [3](#), [4](#), [4](#)

MFM_consumerrisk, [5](#), [6–8](#)
MFM_core, [6](#), [6](#), [7](#), [8](#)
MFM_Indicator, [6](#), [7](#), [8](#)
MFM_optimal_n, [6](#), [7](#), [8](#)
MP_Indicator, [13](#)
MPCum_consumerrisk, [9](#)
MPCum_core, [9](#)
MPCum_optimal_n, [10](#)
MPSep_consumerrisk, [11](#)
MPSep_core, [12](#)
MPSep_optimal_n, [12](#)

pi_MCSim_beta, [14](#), [15](#)
pi_MCSim_dirichlet, [14](#), [14](#)